

VT8237 SATA RAID User Manual

Enter BIOS Configuration Utility

When the system powers on, the following information will appear on screen. Press the 'Tab' key to enter BIOS configuration utility.

```
VIA Technologies,Inc.VIA Serial ATA RAID BIOS Setting Utility v1.00
Copyright (C) VIA Technologies,Inc.All Right reserved.
```

```
Scan Devices,Please wait . . .
Press < Tab > Key into User Window!
Channel 0 Master: IC35L040AVVA07-0
Channel 1 Master: IC35L040AVVA07-0
```

The main interface of BIOS configuration utility is as below:

VIA Tech. RAID BIOS Ver 1.00						
<ul style="list-style-type: none"> ▶ Create Array ▶ Delete Array ▶ Create/Delete Spare ▶ Select Boot Array ▶ Serial Number View 		Create a RAID array with the hard disks attached to VIA IDE controller F1 : View Array/disk Status ↑↓ : Move to next item Enter : Confirm the selection ESC : Exit				
Channel	Drive Name	Array Name	Mode	Size(GB)	Status	
Channel0	Master IC35L040AVVA07-0		ATA 100	38.34	Hdd	
Channel1	Master IC35L040AVVA07-0		ATA 100	38.34	Hdd	

Create Disk Array

1. Use the arrow keys to navigate the main menu. Use the up and down arrow keys to select the **Create Array** command and press <Enter> to call out the list of creation steps.

VIA Tech. RAID BIOS Ver 1.00

<ul style="list-style-type: none"> ▶ Auto Setup For Data Security ▶ Array Mode RAID 1 (Mirroring) ▶ Select Disk Drives ▶ Start Create Process 	<p>Create a RAID array with the hard disks attached to VIA IDE controller</p> <p>F1 : View Array/disk Status ↑↓ : Move to next item Enter : Confirm the selection ESC : Exit</p>																				
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Channel</th> <th>Drive Name</th> <th>Array Name</th> <th>Mode</th> <th>Size(GB)</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>Channel0</td> <td>Master</td> <td>IC35L040AVVA07-0</td> <td>ATA</td> <td>100</td> <td>38.34</td> <td>Hdd</td> </tr> <tr> <td>Channel1</td> <td>Master</td> <td>IC35L040AVVA07-0</td> <td>ATA</td> <td>100</td> <td>38.34</td> <td>Hdd</td> </tr> </tbody> </table>		Channel	Drive Name	Array Name	Mode	Size(GB)	Status	Channel0	Master	IC35L040AVVA07-0	ATA	100	38.34	Hdd	Channel1	Master	IC35L040AVVA07-0	ATA	100	38.34	Hdd
Channel	Drive Name	Array Name	Mode	Size(GB)	Status																
Channel0	Master	IC35L040AVVA07-0	ATA	100	38.34	Hdd															
Channel1	Master	IC35L040AVVA07-0	ATA	100	38.34	Hdd															

2. Highlight the **Array Mode** and press <Enter>, then a list of array modes will appear. Just highlight the target array mode that you want to create, and press <Enter> to

VIA Tech. RAID BIOS Ver 1.00

<ul style="list-style-type: none"> ▶ RAID 0 for performance ▶ RAID 1 for data protection ▶ RAID SPAN for capacity 	<p>Create a RAID array with the hard disks attached to VIA IDE controller</p> <p>F1 : View Array/disk Status ↑↓ : Move to next item Enter : Confirm the selection ESC : Exit</p>																				
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Channel</th> <th>Drive Name</th> <th>Array Name</th> <th>Mode</th> <th>Size(GB)</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>Channel0</td> <td>Master</td> <td>IC35L040AVVA07-0</td> <td>ATA</td> <td>100</td> <td>38.34</td> <td>Hdd</td> </tr> <tr> <td>Channel1</td> <td>Master</td> <td>IC35L040AVVA07-0</td> <td>ATA</td> <td>100</td> <td>38.34</td> <td>Hdd</td> </tr> </tbody> </table>		Channel	Drive Name	Array Name	Mode	Size(GB)	Status	Channel0	Master	IC35L040AVVA07-0	ATA	100	38.34	Hdd	Channel1	Master	IC35L040AVVA07-0	ATA	100	38.34	Hdd
Channel	Drive Name	Array Name	Mode	Size(GB)	Status																
Channel0	Master	IC35L040AVVA07-0	ATA	100	38.34	Hdd															
Channel1	Master	IC35L040AVVA07-0	ATA	100	38.34	Hdd															

3. After selected array mode, there are two methods to create a disk array. One method is “**Auto Setup**” another is “**Select Disk Drives**”. **Auto Setup** let BIOS select the disk drives and create array automatically. **Select Disk Drives** let user select the array drives by required. When using **Select Disk Drives** method, the channel column will be activated. Just highlight the target drives that you want to use and press <Enter> to select them respectively. After all drives have been selected, press <Esc> to go back to the creation steps menu.

VIA Tech. RAID BIOS Ver 1.00

<ul style="list-style-type: none"> ▶ Auto Setup For Performance ▶ Array Mode RAID 0 (Striping) ▶ Select Disk Drives ▶ Block Size 64K ▶ Start Create Process 	<p>Create a RAID array with the hard disks attached to VIA IDE controller</p> <p>F1 : View Array/disk Status ↑↓ : Move to next item Enter : Confirm the selection ESC : Exit</p>																		
<table border="1"> <thead> <tr> <th>Channel</th> <th>Drive Name</th> <th>Array Name</th> <th>Mode</th> <th>Size(GB)</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>[*]Channel0 Master</td> <td>IC35L040AVVA07-0</td> <td></td> <td>ATA 100</td> <td>38.34</td> <td>Stripe0</td> </tr> <tr> <td>[]Channel1 Master</td> <td>IC35L040AVVA07-0</td> <td></td> <td>ATA 100</td> <td>38.34</td> <td>Hdd</td> </tr> </tbody> </table>		Channel	Drive Name	Array Name	Mode	Size(GB)	Status	[*]Channel0 Master	IC35L040AVVA07-0		ATA 100	38.34	Stripe0	[]Channel1 Master	IC35L040AVVA07-0		ATA 100	38.34	Hdd
Channel	Drive Name	Array Name	Mode	Size(GB)	Status														
[*]Channel0 Master	IC35L040AVVA07-0		ATA 100	38.34	Stripe0														
[]Channel1 Master	IC35L040AVVA07-0		ATA 100	38.34	Hdd														

4. If user selected a RAID 0 array in step 2, user also can select a block size for the array. Use the arrow key to highlight the Block Size and press <Enter>, then select a block size from will pop up. The block size can be selected from 4K to 64K Bytes.

VIA Tech. RAID BIOS Ver 1.00

<ul style="list-style-type: none"> ▶ Auto Setup For ▶ Array Mode RAID ▶ Select Disk Dri ▶ Block Size 64K ▶ Start Create Pr 	<table border="1"> <tr><td>4K</td></tr> <tr><td>8K</td></tr> <tr><td>16K</td></tr> <tr><td>32K</td></tr> <tr><td>64K</td></tr> </table>	4K	8K	16K	32K	64K	<p>Create a RAID array with the hard disks attached to VIA IDE controller</p> <p>F1 : View Array/disk Status ↑↓ : Move to next item Enter : Confirm the selection ESC : Exit</p>													
4K																				
8K																				
16K																				
32K																				
64K																				
<table border="1"> <thead> <tr> <th>Channel</th> <th>Drive Name</th> <th>Array Name</th> <th>Mode</th> <th>Size(GB)</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>[*]Channel0 Master</td> <td>IC35L040AVVA07-0</td> <td></td> <td>ATA 100</td> <td>38.34</td> <td>Stripe0</td> </tr> <tr> <td>[*]Channel1 Master</td> <td>IC35L040AVVA07-0</td> <td></td> <td>ATA 100</td> <td>38.34</td> <td>Stripe1</td> </tr> </tbody> </table>			Channel	Drive Name	Array Name	Mode	Size(GB)	Status	[*]Channel0 Master	IC35L040AVVA07-0		ATA 100	38.34	Stripe0	[*]Channel1 Master	IC35L040AVVA07-0		ATA 100	38.34	Stripe1
Channel	Drive Name	Array Name	Mode	Size(GB)	Status															
[*]Channel0 Master	IC35L040AVVA07-0		ATA 100	38.34	Stripe0															
[*]Channel1 Master	IC35L040AVVA07-0		ATA 100	38.34	Stripe1															

5. Use the arrow key to highlight **Start Create Process** and press <Enter>. A warning message will appear, press **Y** to finish the creation, or press **N** to cancel the creation.
6. Please note that all existing content in the hard drive will be destroyed after the array creation.

Delete Disk Array

A specific RAID can be deleted after it has been created. To delete a created RAID, please use the following steps:

1. Select **Delete Array** in the main menu and press <Enter>. The channel column will be activated.
2. Select the member of an array that is to be deleted and press <Enter>. A warning message will show up, press **Y** to delete or press **N** to cancel.

VIA Tech. RAID BIOS Ver 1.00

<ul style="list-style-type: none"> ▶ Create Array ▶ Delete Array ▶ Create/Delete Spare ▶ Select Boot Array ▶ Serial Number View <p>The selected array will be destroyed Are you sure? Continue? Press Y/N</p>	<p>Delete a RAID array contain the hard disks attached to VIA IDE controller</p> <p>F1 : View Array/disk Status ↑↓ : Move to next item Enter : Confirm the selection ESC : Exit</p>
--	--

Channel	Drive Name	Array Name	Mode	Size(GB)	Status
[*] Channel0 Master	IC35L040AVVA07-0	ARRAY 0	ATA 100	38.34	Stripe0
[*] Channel1 Master	IC35L040AVVA07-0	ARRAY 0	ATA 100	38.34	Stripe1

Deleting a disk array will destroy all the data on the disk array except RAID 1 arrays. When a RAID 1 is deleted, the data on these two hard disk drives will be reserved and become two normal disk drives.

Select Boot Array

User can select a disk array as boot device if user wants to boot operating system from an array. Boot disk array can be not selected if user does not boot operating system from disk array. Use the arrow key to highlight the Select Boot Disk item then press <Enter>. The channel column will be activated. Just use arrow key to highlight the target disk array then press <Enter>. If user select a disk array that has a boot mark and press <Enter>, then its boot setting will be canceled.

VIA Tech. RAID BIOS Ver 1.00

<ul style="list-style-type: none"> ▶ Create Array ▶ Delete Array ▶ Create/Delete Spare ▶ Select Boot Array ▶ Serial Number View 	<p style="text-align: center;">Sct/Clear bootable array</p> <p>F1 : View Array/disk Status ↑↓ : Move to next item Enter : Confirm the selection ESC : Exit</p>
--	---

Channel	Drive Name	Array Name	Mode	Size(GB)	Status
[*] Channel0 Master	IC35L040AVVA07-0	ARRAY 0	ATA 100	38.34	Boot
[*] Channel1 Master	IC35L040AVVA07-0	ARRAY 0	ATA 100	38.34	Boot

Duplicate Critical RAID 1 Array

When booting up the system, BIOS will detect if the RAID 1 array has any inconsistencies between user data and backup data. If BIOS detects any inconsistencies, the status of the disk array will be marked as critical, and BIOS will prompt the user to duplicate the RAID 1 in order to ensure the backup data consistency with the user data.

Critical RAID 1	Critical Status
<p>Duplicate now Continue to boot</p>	<p>the RAID 1 array needs to be duplicated to ensure data consistency.</p> <p>Fault Hdd Found: Channel 1 Device 0 Fault</p>

Remaining members of the failed array					
Channel	Drive Name	Array Name	Mode	Size(GB)	Status
Channel1 Device0	IC35L040AVVA07-0	Array0	ATA 100	38.34	Mirror
Channel0 Device0	IC35L040AVVA07-0	Array0	ATA 100	38.34	Source

Note:
 1) Press <ESC> to Exit.
 2) After Execute, Press <TAB> immediately can into Utility Window!

If user selects Continue to boot, it will enable duplicating the array after booting into OS.

Rebuild Broken RAID 1 Array

When booting up the system, BIOS will detect if any member disk drives of RAID has failed or is absent. If BIOS detects any disk drive failures or missing disk drives, the status of the array will be marked as broken.

If BIOS detects a broken RAID 1 array but there is a spare hard drive available for rebuilding the broken array, the spare hard drive will automatically become the mirroring drive. BIOS will show a main interface just like a duplicated RAID 1. Selecting **Continue to boot** enables the user to duplicate the array after booting into operating system.

Broken RAID 1		Critical Status			
<p>Power off and check the failed drive Destroy the Mirroring Relationship Choose replacement drive and rebuild Continue to boot</p>		<p>A disk member of a mirroring array has failed or is not responding. The array is stilling functional, but fault tolerance is disabled.</p>			
Remaining members of the failed array					
Channel	Drive Name	Array Name	Mode	Size(GB)	Status
Channel0	Device0	IC35L040AVVA07-0	Array0	ATA 100	38.34 Broken
<p>Note: 1) Press <ESC> to Exit. 2) After Execute, Press <TAB> immediately can into Utility Window!</p>					

1. Power off and Check the Failed Drive:

This item enables users to turn off the computer and replace the failed hard drive with a good one. If users' computer does not support APM, the computer would need to be turned off manually. After the replacement, users can boot into BIOS and select **3 Choose replacement drive and rebuild** to rebuild the broken array.

2. Destroy the Mirroring Relationship:

This item enables users to cancel the data mirroring relationship of the broken array. For broken RAID 1 array, the data on the surviving disk will remain after the destroy operation.

However, **Destroy the Mirroring Relationship** is not recommend because the data on the remaining disk will be lost when the hard drive is used to create another RAID 1 array.

3. Choose Replacement Drive and Rebuild:

This item enables users to select an already-connected hard drive to rebuild the broken array and replace the data to that particular hard drive. After choosing the item, the channel column will be activated.

Broken RAID 1				Critical Status		
Power off and check the failed drive Destroy the Mirroring Relationship Choose replacement drive and rebuild Continue to boot				The contents on the disk you have selected will be deleted.		
Remaining members of the failed array						
Channel	Drive Name	Array Name	Mode	Size(GB)	Status	
() Channel1	Device0	IC35L040AVVA07-0	ATA	100	38.34	Hdd
Note: 1) Press <ESC> to Exit. 2) After Execute, Press <TAB> immediately can into Utility Window!						

Highlight the target hard drive and press <Enter>, a warning message will appear. Press **Y** to use that hard drive to rebuild, or press **N** to cancel. Please note by selecting option **Y**, all the data on the selected hard drive will be destroyed.

4. Continue to boot:

This item enables BIOS to skip the problem and continue booting into OS.

DRIVER AND RAID SOFTWARE INSTALLATION

Microsoft Windows Driver Installation

1. After Windows has finished booting up, the system will automatically find the newly installed adapter and prompt the **Found New Hardware Wizard** window. Click **Cancel** to skip it.



2. Insert the bundled driver CD DISC into your CD-ROM drive, select **Serial ATA RAID Driver** installation bar on the dialogue Window to begin the driver and software installation.

3. Confirm the follow-up dialogue windows to finish the installation.



4. When installation is completed, click **Finish** to restart the system.



Install Operating System into SATA HDD of VT8237

Install Windows 98SE or Me

1. Make sure the HDD wanted for installing the OS is in the first hard disk drive(C:\).
2. Install OS.
3. Install driver after OS is installed.

Install Windows NT 4.0,2000,XP

1. Insert the bundled driver CD DISC into CD-ROM(G:). Copy all files and directories of G:\VIA chipset\SATA_Raid\DriverDisk\SATA folder to a floppy disk. Make sure following directories and files are copied into floppy disk.

A:\

\Win2000

 VIAraid.inf
 VIAraid.sys
 VIAraid.cat

\Winnt40

 VIAraid.inf
 VIAraid.sys

\WinXP

 VIAraid.inf
 VIAraid.sys
 VIAraid.cat

 Txtsetup.oem
 VT8237

2. Install OS from CD-ROM.
3. Press "F6" when display "Press F6 if you need to install a third party SCSI or RAID driver..."
4. Insert floppy disk.
5. Choose the OS device driver wanted for loading.
6. Install OS.
7. Install driver after OS is installed.

APPENDIX

Note to User:

1. The bundled driver CD attached an Auto-Run feature for all the drivers that the motherboard need. Please select the drivers that you want to install and click the button on the installation panel.
 2. This motherboard support USB2.0 feature only on Windows® 2000/XP OS.
-